

# APCO Wonder Bar

## Fitting Instructions

Congratulations! You have made the best purchase of your life (so far). The new Wonder Bar will transform your life, making your bar easier to get hold of and giving you stress free access to an extra 100mm (no pills required) leading to better penetration in all conditions.



1. Your Wonder Bar will look like this. Unravel the lines, but DO NOT pull them through the bar as they are very hard to re-thread.



2. Take off the brummel hooks.



3. Pass the stitched loop over the top of the hook.



4. Release the hook by pulling the line through the eye like this.



5. Thread the line through your harness pulley system. Sometimes the loop is hard to get through the pulleys. When it is threaded through, reverse steps 2 to 4 to reconnect the brummel hooks.



6. The length of the lines is adjusted by moving the knot where it stops against the end of the bar. Make sure you don't set it overtight so that the accelerator system is being applied before pushing the bar.

You are now ready to experience the full potential of your wing.